Lab report no 1



Spring 2022 CSE303L Data Communication Network

Submitted by: Muhammad Ali

Registration No: - 19pwcse1801

Class Section: A

Submitted to:

Engr. Faizullah

Date: Friday 22, 2022

Department of Computer Systems Engineering
University of Engineering and Technology, Peshawar

CSE 303L: Data Communication and Computer Networks

Credit Hours: 1

Contact Hours: 3

LAB ASSESSMENT RUBRIC

Demonstration of Concepts	Poor (Does not meet expectation (1))	Fair (Meet Expectation (2- 3))	Good (Exceeds Expectation (4- 5)	Score
	The student failed to demonstrate a clear understanding of the assignment concepts	The student demonstrated a clear understanding of some of the assignment concepts	The student demonstrated a clear understanding of the assignment concepts	30%
Accuracy	The student misconfigured enough network settings that the lab computer couldn't function properly on the network	The student configured enough network settings that the lab computer partially functioned on the network	The student configured the network settings that the lab computer fully functioned on the network	
				30%
Following Directions	The student clearly failed to follow the verbal and written instructions to successfully complete the lab	The student failed to follow the some of the verbal and written instructions to successfully complete all requirements of the lab	The student followed the verbal and written instructions to successfully complete requirements of the lab	
				20%

Time Utilization	The student failed to complete even part of the lab in the allotted amount of time	The student failed to complete the entire lab in the allotted amount of time	The student completed the lab in its entirety in the al	
				20%

Lab₀₁

PC Network TCP/IP Configuration

OBJECTIVES OF THE LAB

Following topics will be covered in this lab

- Gather information including connection, host name, Layer 2 MAC address and Layer 3 TCP/IP network address information.
- Compare network information to other PCs on the network.
- Identify tool used for discovering a computer's network configuration.

ABOUT IPCONFIG

ipconfig (**Internet Protocol Configuration**) in Microsoft Windows is a console application. It can be used from MS-DOS shell to display the network settings currently assigned and given by a network. This command can be utilized to verify a network connection as well as to verify network settings. **Usage**

ipconfig [/allcompartments] [/? | /all | /renew [adapter] | release [adapter] |/flushdns | /displaydns
/registerdns | /showclassid adapter | /setclassid adapter [classidtoset]] Option Description

/? Display help message

/all Display full configuration information

/allcompartments Display information for all compartments

/release Release the IP address for the specified adapter

/renew Renew the IP address for the specified adapter

/flushdns Removes the DNS Resolver cache

/registerdns Refreshes all DHCP leases and re-registers DNS name

/displaydns Display the contents of the DNS Resolver Cache
/showclassid Displays all the DHCP class IDs allowed for adapter

/setclassid Modifies the DHCP class ID

The default is to display only the IP address, subnet mask and default gateway for each adapter bound to TCP/IP.

Gathering TCP/IP configuration information

Step 1

Establish and verify connectivity to the Internet. This ensures the computer has an IP address.

Step 2

Use the Start menu to open the Command Prompt, an MS-DOS-like window. Press Start >

Programs > Accessories > Command Prompt

OR

Start > Programs > Command Prompt.

OR

Press Start>Run Then type cmd.

The following figure shows the Command screen. Type ipconfig and press the Enter key. The spelling of ipconfig is critical while case is not. It is short for IP Configuration.

Figure 1.1 Command Screen for ipconfig

Figure 1.2 Command Screen for ipconfig

This first screen shows the IP address, subnet mask, and default gateway. The IP address and the default gateway should be in the same network or subnet, otherwise this host would not be able to communicate outside the network. In the figure the subnet mask tells us that the first three octets must be the same to be in the same network.

Note: If this computer is on a LAN, the default gateway might not be seen if it is running behind a Proxy Server. Record the following information for this computer.

Step 3Record the following TCP/IP information for atleast THREE computers

	Computer 1	Computer 2 (Neighbor 1)	Computer 3 (Neighbor 1)
IP Address	192.168.137.247	192.168.137.254	192.168.137.48
Subnet Mask	255.255.255.0	255.255.255.0	255.255.255.0
Default Gateway	192.168.137.1	192.168.137.1	192.168.137.1
DNS Address	192.168.137.1	192.168.137.1	192.168.137.1
DHCP Address	192.168.137.1	192.168.137.1	192.168.137.1

Difference between Fig.1 and Fig.2:

Step 4

Compare the TCP/IP configuration of this computer to others on the LAN

If this computer is on a LAN, compare the information of several machines.

address are same
What is similar about the IP addresses?
What is similar about the default gateways? default gateway are same on the LAN.

The IP addresses should share the same network portion. All machines in the LAN should share the same default gateway.

Record a couple of the IP Addresses:

Step 5

Check additional TCP/IP configuration information

To see detailed information, type ipconfig /all and press Enter. The figure shows the detailed IP configuration screen.

```
C:\WINDOWS\system32\cmd.exe
Microsoft Windows XP [Version 5.1.2600]
(C) Copyright 1985-2001 Microsoft Corp.
C:\Documents and Settings\Waqas>ipconfig /all
Windows IP Configuration
          waqas-pc
                                                        Unknown
Ethernet adapter Wireless Network Connection:
          Connection-specific DNS Suffix .
                                                     : Intel(R) PRO/Wireless 3945ABG Networ
          Description . . . . . . . . . . . .
  Connection
Physical Address...
Dhcp Enabled...
Autoconfiguration Enabled.
                                                        00-1F-3C-5C-F8-C7
Yes
Yes
192.168.1.3
255.255.255.0
192.168.1.1
          172.168.1.1
192.168.1.1
192.168.1.1
Saturday, June 04, 2011 10:30:06 AM
Saturday, June 04, 2011 11:30:06 AM
Ethernet adapter Local Area Connection:
          Media State
Description
                                                        Media disconnected
Intel(R) PRO/100 VE Network Connecti
                                                 . . : 00-1E-EC-6D-B3-63
          Physical Address. . .
 :\Documents and Settings\Waqas>_
```

Figure 1.3 Command Screen for ipconfig /all

The host name, including the computer name and NetBIOS name should be displayed. Also, the

DHCP server address, if used, and the date the IP lease starts and ends should be displayed. Look over the information. Entries for the DNS, used in name resolution servers, may also be present.

The previous figure reveals that the router is performing both DHCP and DNS services for this network. This would likely be a small office or home office (SOHO) or small branch office implementation.

Notice the Physical Address (MAC) and the NIC model (Description).

_____ E4-A7-A0-35-64-B6_______

Write down the IP addresses of any servers listed:

192.168.137.247(Preferred)
Write down the computer Host Name:
DESKTOP-I9MQBNU
Write down the Host Names of a couple other computers:
Mohsin laptop
Do all of the servers and workstations share the same network portion of the IP address as
the student workstation?YES
It would not be unusual for some or all of the servers and workstations to be in another network.
It means that the computer default gateway is going to forward requests to the other network.

Step 6

Close the screen when finished examining network settings.

Repeat the previous steps as necessary. Make sure that it is possible to return to and interpret this screen.

Based on observations, what can be deduced about the following results taken from three computers connected to one switch?

Computer 1

IP Address: 192.168.5.13

Subnet Mask: 255.255.255.0

Default Gateway: 192.168.12.1

Computer 2

IP Address: 192.168.5.5

Subnet Mask: 255.255.255.0

Default Gateway: 192.168.12.1

Computer 3

IP Address: 192.168.11.97

Subnet Mask: 255.255.255.0

Default Gateway: 192.168.12.1

Should they be able to talk to each other?

Are they all on the same network? Why or why not?

They are on the same network because of their similar default gateway.